

Storage instruction



In order to prevent degeneration of stainless steel repair clamps, below mentioned storage instructions should be followed:

Hygiene

It is advised to store the repair clamps in a cool, dry, clean and dust-free environment. Especially when using the products for drinking water or other hygienic environments, a clean storage facility is of great importance. Storing the product in the same area with products such as chemicals or oil products should be avoided at all times.

Light

The repair clamps cannot be stored in direct sunlight because of the rubber gasket, contact with UV light or ozone should be avoided at all times.

Temperature

The product is preferably stored at room temperature and cannot be stored in the direct presence of heating elements such as boilers or radiators, the storage temperature should be 5-35°C.

Storage position

Repair clamps are preferably always stored in an upright position.